



XI-1500 Inter-Building Access Point **Reset Procedure**

A Reset button is provided in the back of the Access Point (AP) to allow the user to reset the parameters entered in the unit to the factory default values, the following procedure shows step by step how you can do it.

Resetting Procedure

To reset the AP proceed as follows:

1. Power down the AP.
2. While holding the Reset button pressed, apply power to the AP.
3. Wait until the AP Activity LED, start to flash on and off continuously.
4. Release the Reset Button.
5. Login into the unit without power off.
6. Go to under "Configuration" and then "General" option and press "Apply" button.
7. Then press "Ok" button and wait for the unit to reset one more time, now your unit should be reseted.