



# SmartAmp 2 Watt 900MHz

## General Connection Instructions

1. Connect the amplifier in the network as shown in Figure 1.
2. Connect DC Injector to 9V DC Power Supply.
3. Connect DC Injector (labeled "TO RADIO") to Radio by using Type N plug cable (Not supplied).
4. Connect DC Injector (labeled "TO AMPLIFIER") to SmartAmp 900MHz Series Amplifier (labeled "TO INJECTOR") using Type N plug connector (Not supplied).
5. Connect SmartAmp 900MHz Series Amplifier (labeled "TO ANTENNA") to input of antenna using Type N plug cable (Not supplied).

Figure 1: Connection Modules




Figure 2: Product Figure

